# AF120(-S) US, AF230(-S) US

On/Off, Spring Return, 120 or 230 VAC









Technical Data	AF120 US, AF230 US
Power supply	
AF120(-S) US	120 VAC ± 10% 50/60 Hz
AF230(-S) US	230 VAC ±15% 50/60 Hz
Power consumption	
AF120(-S) US running	8 W
holding	
AF230(-S) US running	8.5 W
holding	3 W
Transformer sizing	
AF120(-S) US	11 VA
AF230(-S) US	11 VA
Electrical connection	3 ft, 18 GA appliance cable
(-S models have 2 cables)	1/2" conduit connector
Electrical protection	actuators are double insulated
Overload protection	electronic throughout 0° to 95° rotation
Angle of rotation	95°, adjustable 35 to 95° w/ZDB-AF2 US
Torque	133 in-lb [15 Nm] constant
Direction of rotation	reversible with CW/CCW mounting
Position indication	visual indicator, 0° to 95°
	(0° is spring return position)
Manual override	3mm hex crank (shipped w/actuator)
Auxiliary switches	2 x SPDT 7A (2.5A) @ 250 VAC, UL approved
(AF120/230-S)	one set at +5°, one adjustable 25° to 85°
Running time	150 seconds constant, independent of load,
	spring return < 20 seconds
Humidity	5 to 95% RH non-condensing
Ambient temperature	-22°F to 122°F [-30°C to 50°C]
Storage temperature	-40°F to 176°F [-40°C to 80°C]
Housing	NEMA type 2 / IP54
Housing material	zinc coated steel
Agency listings	cULus acc. to UL 873 and
	CAN/CSA C22.2 No. 24-93
Noise level	max. 45 dB (A)
Servicing	maintenance free
Quality standard	ISO 9001
Weight	6.9 lbs (3.1 kg)

#### Torque min. 133 in-lb, for control of air dampers

### Application

For On/Off, fail-safe control of dampers in HVAC systems. Actuator sizing should be done in accordance with the damper manufacturer's specifications. Control is On/Off from an auxiliary contact, or a manual switch.

The actuator is mounted directly to a damper shaft up to  $1.05^{\circ}$  in diameter by means of its universal clamp. A crank arm and several mounting brackets are available for applications where the actuator cannot be direct coupled to the damper shaft.


#### Operation

The AF series actuators provide true spring return operation for reliable fail-safe application and positive close off on air tight dampers. The spring return system provides consistent torque to the damper with, and without, power applied to the actuator.

The AF series provide 95° of rotation and are provided with a graduated position indicator showing 0° to 95°. The AF has a unique manual positioning mechanism which allows the setting of any damper position within its 95° of rotation. The AF series actuators are shipped at  $+5^{\circ}$  (5° from full fail-safe) to provide automatic compression against damper gaskets for tight shut-off. When power is applied to the AF series, the manual mechanism is released. The actuators will now try to close against the 0° position during its normal control operations. The manual override can also be released physically by the use of a crank supplied with the actuator.

The AF uses a brushless DC motor which is controlled by an Application Specific Integrated Circuit (ASIC). The ASIC monitors and controls the actuator's rotation and provides a digital rotation sensing function to prevent damage to the actuator in a stall condition. The actuator may be stalled anywhere in its normal rotation without the need of mechanical end switches. The actuators are Double Insulated so a ground connection is not required.

The AF120/230-S US version is provided with two built-in auxiliary switches. These SPDT switches are provided for safety interfacing or signaling, for example, for fan start-up. The switching function at the fail-safe position is fixed at  $+5^{\circ}$ , the other switch function is adjustable between  $+25^{\circ}$  to  $+85^{\circ}$ .



# AF120(-S) US, AF230(-S) US

On/Off, Spring Return, 120 or 230 VAC



AV 10-18   Shaft extension     IND-AF2   Damper position indicator     K4 US   Universal clamp for 3/8" to 3/4" shafts     K4-1 US   Universal clamp for up to 1.05" dia jackshafts     KH-AF   Crank arm for up to 3/4" round shaft (Series 2)     KH-AF-1   Crank arm for up to 1.05" jackshaft (Series 2)     KH-AF-1   Crank arm for up to 1.05" jackshaft (Series 2)     KH-AFV   V-bolt kit for KH-AF and KH-AF-1     Tool-06   8mm and 10 mm wrench     ZG-HTR   Thermostat/Heater Kit     ZDB-AF2 US   Angle of rotation limiter     ZG-100   Universal mounting bracket     ZG-101   Universal mounting bracket     ZG-102   Multiple actuator mounting bracket     ZG-103   Mounting bracket for Honeywell® Mod IV replacement or new crank arm type installations     ZG-106   Mounting bracket for Barber Colman® MA 3/4,     Honeywell® Mod III or IV or Johnson® Series 100 replacement or new crank arm type installations     ZG-108   Mounting bracket for Barber Colman® MA 3/4,     Honeywell® Mod III or IV or Johnson® Series 100 replacement or new crank arm type installations     ZG-AFIUS   Crank arm adaptor kit for AF/NF     ZG-AFI08   Crank arm adaptor kit for AF/NF <th>Accessories</th> <th></th>	Accessories	
K4 US   Universal clamp for 3/8" to 3/4" shafts     K4-1 US   Universal clamp for up to 1.05" dia jackshafts     KH-AF   Crank arm for up to 3/4" round shaft (Series 2)     KH-AF-1   Crank arm for up to 1.05" jackshaft (Series 2)     KH-AF-1   Crank arm for up to 1.05" jackshaft (Series 2)     KH-AFV   V-bolt kit for KH-AF and KH-AF-1     Tool-06   8mm and 10 mm wrench     ZG-HTR   Thermostat/Heater Kit     ZDB-AF2 US   Angle of rotation limiter     ZG-100   Universal mounting bracket     ZG-101   Universal mounting bracket     ZG-102   Multiple actuator mounting bracket     ZG-106   Mounting bracket for Honeywell® Mod IV replacement or new crank arm type installations     ZG-107   Mounting bracket for Barber Colman® MA 3/4, Honeywell® Mod III or Johnson® Series 100 replacement or new crank arm type installations     ZG-108   Mounting bracket for AF/NF     ZG-AF US   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZS-100   Weather shield (metal)	AV 10-18	Shaft extension
K4-1 US   Universal clamp for up to 1.05" dia jackshafts     KH-AF   Crank arm for up to 3/4" round shaft (Series 2)     KH-AF-1   Crank arm for up to 1.05" jackshaft (Series 2)     KH-AF-1   Crank arm for up to 1.05" jackshaft (Series 2)     KH-AFV   V-bolt kit for KH-AF and KH-AF-1     Tool-06   8mm and 10 mm wrench     ZG-HTR   Thermostat/Heater Kit     ZDB-AF2 US   Angle of rotation limiter     ZG-100   Universal mounting bracket     ZG-101   Universal mounting bracket     ZG-102   Multiple actuator mounting bracket     ZG-106   Mounting bracket for Honeywell® Mod IV replacement or new crank arm type installations     ZG-107   Mounting bracket for Honeywell® Mod III or Johnson® Series 100 replacement or new crank arm type installations     ZG-108   Mounting bracket for Barber Colman® MA 3/4, Honeywell® Mod III or IV or Johnson® Series 100 replacement or new crank arm type installations     ZG-AF US   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZS-100   Weather shield (metal)	IND-AF2	Damper position indicator
KH-AF   Crank arm for up to 3/4" round shaft (Series 2)     KH-AF-1   Crank arm for up to 1.05" jackshaft (Series 2)     KH-AFV   V-bolt kit for KH-AF and KH-AF-1     Tool-06   8mm and 10 mm wrench     ZG-HTR   Thermostat/Heater Kit     ZDB-AF2 US   Angle of rotation limiter     ZG-100   Universal mounting bracket     ZG-101   Universal mounting bracket     ZG-102   Multiple actuator mounting bracket     ZG-106   Mounting bracket for Honeywell® Mod IV replacement or new crank arm type installations     ZG-107   Mounting bracket for Honeywell® Mod III or Johnson® Series 100 replacement or new crank arm type installations     ZG-108   Mounting bracket for Barber Colman® MA 3/4, Honeywell® Mod III or IV or Johnson® Series 100 replacement or new crank arm type installations     ZG-AF US   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZS-100   Weather shield (metal)	K4 US	Universal clamp for 3/8" to 3/4" shafts
KH-AF-1   Crank arm for up to 1.05" jackshaft (Series 2)     KH-AFV   V-bolt kit for KH-AF and KH-AF-1     Tool-06   8mm and 10 mm wrench     ZG-HTR   Thermostat/Heater Kit     ZDB-AF2 US   Angle of rotation limiter     ZG-100   Universal mounting bracket     ZG-101   Universal mounting bracket     ZG-102   Multiple actuator mounting bracket     ZG-106   Mounting bracket for Honeywell® Mod IV replacement or new crank arm type installations     ZG-107   Mounting bracket for Honeywell® Mod III or Johnson® Series 100 replacement or new crank arm type installations     ZG-108   Mounting bracket for Barber Colman® MA 3/4, Honeywell® Mod III or IV or Johnson® Series 100 replacement or new crank arm type installations     ZG-AF US   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZS-100   Weather shield (metal)	K4-1 US	Universal clamp for up to 1.05" dia jackshafts
KH-AFV   V-bolt kit for KH-AF and KH-AF-1     Tool-06   8mm and 10 mm wrench     ZG-HTR   Thermostat/Heater Kit     ZDB-AF2 US   Angle of rotation limiter     ZG-100   Universal mounting bracket     ZG-101   Universal mounting bracket     ZG-102   Multiple actuator mounting bracket     ZG-106   Mounting bracket for Honeywell® Mod IV replacement or new crank arm type installations     ZG-107   Mounting bracket for Honeywell® Mod III or Johnson® Series 100 replacement or new crank arm type installations     ZG-108   Mounting bracket for Barber Colman® MA 3/4, Honeywell® Mod III or IV or Johnson® Series 100 replacement or new crank arm type installations     ZG-AF US   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZG-AF100   Weather shield (metal)	KH-AF	Crank arm for up to 3/4" round shaft (Series 2)
Tool-06   8mm and 10 mm wrench     ZG-HTR   Thermostat/Heater Kit     ZDB-AF2 US   Angle of rotation limiter     ZG-100   Universal mounting bracket     ZG-101   Universal mounting bracket     ZG-102   Multiple actuator mounting bracket     ZG-106   Mounting bracket for Honeywell® Mod IV replacement or new crank arm type installations     ZG-107   Mounting bracket for Honeywell® Mod III or Johnson® Series 100 replacement or new crank arm type installations     ZG-108   Mounting bracket for Barber Colman® MA 3/4, Honeywell® Mod III or IV or Johnson® Series 100 replacement or new crank arm type installations     ZG-AF US   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZS-100   Weather shield (metal)	KH-AF-1	Crank arm for up to 1.05" jackshaft (Series 2)
ZG-HTR   Thermostat/Heater Kit     ZDB-AF2 US   Angle of rotation limiter     ZG-100   Universal mounting bracket     ZG-101   Universal mounting bracket     ZG-102   Multiple actuator mounting bracket     ZG-106   Mounting bracket for Honeywell® Mod IV replacement or new crank arm type installations     ZG-107   Mounting bracket for Honeywell® Mod III or Johnson® Series 100 replacement or new crank arm type installations     ZG-108   Mounting bracket for Barber Colman® MA 3/4, Honeywell® Mod III or IV or Johnson® Series 100 replacement or new crank arm type installations     ZG-AF US   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZS-100   Weather shield (metal)	KH-AFV	V-bolt kit for KH-AF and KH-AF-1
ZDB-AF2 US   Angle of rotation limiter     ZG-100   Universal mounting bracket     ZG-101   Universal mounting bracket     ZG-102   Multiple actuator mounting bracket     ZG-106   Mounting bracket for Honeywell® Mod IV replacement or new crank arm type installations     ZG-107   Mounting bracket for Honeywell® Mod III or Johnson® Series 100 replacement or new crank arm type installations     ZG-108   Mounting bracket for Barber Colman® MA 3/4, Honeywell® Mod III or IV or Johnson® Series 100 replacement or new crank arm type installations     ZG-AF US   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZS-100   Weather shield (metal)	Tool-06	8mm and 10 mm wrench
ZG-100   Universal mounting bracket     ZG-101   Universal mounting bracket     ZG-102   Multiple actuator mounting bracket     ZG-106   Mounting bracket for Honeywell® Mod IV replacement or new crank arm type installations     ZG-107   Mounting bracket for Honeywell® Mod III or Johnson® Series 100 replacement or new crank arm type installations     ZG-108   Mounting bracket for Barber Colman® MA 3/4, Honeywell® Mod III or IV or Johnson® Series 100 replacement or new crank arm type installations     ZG-AF US   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZS-100   Weather shield (metal)	ZG-HTR	Thermostat/Heater Kit
ZG-101   Universal mounting bracket     ZG-102   Multiple actuator mounting bracket     ZG-106   Mounting bracket for Honeywell® Mod IV replacement or new crank arm type installations     ZG-107   Mounting bracket for Honeywell® Mod III or Johnson® Series 100 replacement or new crank arm type installations     ZG-108   Mounting bracket for Barber Colman® MA 3/4, Honeywell® Mod III or IV or Johnson® Series 100 replacement or new crank arm type installations     ZG-AF US   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZS-100   Weather shield (metal)	ZDB-AF2 US	Angle of rotation limiter
ZG-102   Multiple actuator mounting bracket     ZG-106   Mounting bracket for Honeywell® Mod IV replacement or new crank arm type installations     ZG-107   Mounting bracket for Honeywell® Mod III or Johnson® Series 100 replacement or new crank arm type installations     ZG-108   Mounting bracket for Barber Colman® MA 3/4, Honeywell® Mod III or IV or Johnson® Series 100 replacement or new crank arm type installations     ZG-AF US   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZS-100   Weather shield (metal)	ZG-100	Universal mounting bracket
ZG-106   Mounting bracket for Honeywell® Mod IV replacement or new crank arm type installations     ZG-107   Mounting bracket for Honeywell® Mod III or Johnson® Series 100 replacement or new crank arm type installations     ZG-108   Mounting bracket for Barber Colman® MA 3/4, Honeywell® Mod III or IV or Johnson® Series 100 replacement or new crank arm type installations     ZG-AF US   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZS-100   Weather shield (metal)	ZG-101	Universal mounting bracket
crank arm type installations       ZG-107     Mounting bracket for Honeywell® Mod III or Johnson® Series 100 replacement or new crank arm type installations       ZG-108     Mounting bracket for Barber Colman® MA 3/4, Honeywell® Mod III or IV or Johnson® Series 100 replacement or new crank arm type installations       ZG-AF US     Crank arm adaptor kit for AF/NF       ZG-AF108     Crank arm adaptor kit for AF/NF       ZS-100     Weather shield (metal)	ZG-102	Multiple actuator mounting bracket
ZG-107   Mounting bracket for Honeywell® Mod III or Johnson® Series     100 replacement or new crank arm type installations     ZG-108   Mounting bracket for Barber Colman® MA 3/4,     Honeywell® Mod III or IV or Johnson® Series 100     replacement or new crank arm type installations     ZG-AF US   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZS-100   Weather shield (metal)	ZG-106	Mounting bracket for Honeywell® Mod IV replacement or new
100 replacement or new crank arm type installations     ZG-108   Mounting bracket for Barber Colman® MA 3/4, Honeywell® Mod III or IV or Johnson® Series 100 replacement or new crank arm type installations     ZG-AF US   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZS-100   Weather shield (metal)		crank arm type installations
ZG-108   Mounting bracket for Barber Colman® MA 3/4,     Honeywell® Mod III or IV or Johnson® Series 100     replacement or new crank arm type installations     ZG-AF US   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZS-100   Weather shield (metal)		5
Honeywell® Mod III or IV or Johnson® Series 100 replacement or new crank arm type installations     ZG-AF US   Crank arm adaptor kit for AF/NF     ZG-AF108   Crank arm adaptor kit for AF/NF     ZS-100   Weather shield (metal)		
replacement or new crank arm type installations       ZG-AF US     Crank arm adaptor kit for AF/NF       ZG-AF108     Crank arm adaptor kit for AF/NF       ZS-100     Weather shield (metal)	ZG-108	<b>a</b>
ZG-AF US Crank arm adaptor kit for AF/NF   ZG-AF108 Crank arm adaptor kit for AF/NF   ZS-100 Weather shield (metal)		
ZG-AF108     Crank arm adaptor kit for AF/NF       ZS-100     Weather shield (metal)		replacement or new crank arm type installations
ZS-100 Weather shield (metal)	ZG-AF US	Crank arm adaptor kit for AF/NF
	ZG-AF108	Crank arm adaptor kit for AF/NF
ZS-150 Weather shield (polycarbonate)	ZS-100	Weather shield (metal)
	ZS-150	Weather shield (polycarbonate)
ZS-260 Explosion-proof housing	ZS-260	Explosion-proof housing
ZS-300 NEMA 4X housing	ZS-300	NEMA 4X housing

**NOTE:** When using AF120/230 US and AF120/230-S US actuators, only use accessories listed on this page. For actuator wiring information and diagrams, refer to Belimo Wiring Guide.

## **Typical Specification**

On/Off spring return damper actuators shall be direct coupled type which require no crank arm and linkage and be capable of direct mounting to a jackshaft up to a 1.05" diameter. The actuators must be designed so that they may be used for either clockwise or counterclockwise fail-safe operation. Actuators shall have a manual positioning mechanism accessible on its cover. Actuators shall use a brushless DC motor and be protected from overload at all angles of rotation. Run time shall be constant and independent of torque. If required, two SPDT auxiliary switches shall be provided with one switch having the capability of being adjustable. Actuators must be constructed to meet the requirement for Double Insulation so an electrical ground connection is not required to meet agency listings. Actuators shall be cULus listed, have a 5 year warranty, and be manufactured under ISO 9001 International Quality Control Standards. Actuators shall be as manufactured by Belimo.

### Wiring Diagrams

# 🗡 INSTALLATION NOTES

- 1 Provide overload protection and disconnect as required.
- **CAUTION** Equipment Damage!

Actuators may be connected in parallel. Power consumption and input impedance must be observed.

3 No ground connection is required.

For end position indication, interlock control, fan startup, etc., AF120/240-S US incorporates two built-in auxiliary switches: 2 x SPDT, 7A (2.5A) @250 VAC, UL Approved, one switch is fixed at +5°, one is adjustable 25° to 85°.

# APPLICATION NOTES

Meets cULus requirements without the need of an electrical ground connection.

## WARNING Live Electrical Components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.

